

**FW**  
**P1.00**



IS240 Rev.03 30/07/2021

# B70/2ML

## centrale di comando per cancelli battenti

Istruzioni originali

**ROGER**  
BRUSHLESS



- IT - Istruzioni ed avvertenze per l'installatore
- EN - Instructions and warnings for the installer
- DE - Anweisungen und Hinweise für den Installateur
- FR - Instructions et consignes pour l'installateur
- ES - Instrucciones y advertencias para el instalador
- PT - Instruções e advertências para o instalador
- NL - Aanwijzingen en waarschuwingen voor de installateur
- PL - Instrukcja i ostrzeżenia dla instalatora

**ROGER**<sup>®</sup>  
TECHNOLOGY



# INDICE • INDEX • INDEX • INDEXER • ÍNDICE • ÍNDICE • INDEX • INDEKS

## ITALIANO

1	Avvertenze generali	18
	Dichiarazione di Conformità	20
2	Simbologia	21
3	Descrizione prodotto	21
4	Caratteristiche tecniche prodotto	22
5	Descrizione dei collegamenti	23
5.1	Installazione tipo	23
5.2	Collegamenti elettrici	24
6	Comandi e accessori	25
7	Tasti funzione e display	27
8	Accensione o messa in servizio	27
9	Modalità funzionamento display	27
9.1	Modalità visualizzazione dei parametri	27
9.2	Modalità visualizzazione di stato comandi e sicurezze	28
9.3	Modalità TEST	28
9.4	Modalità Stand By	28
10	Apprendimento della corsa	29
10.1	Prima di procedere	29
10.2	Procedura di apprendimento	30
11	Indice dei parametri	31
12	Menù parametri	34
13	Segnalazione degli ingressi di sicurezza e dei comandi (modalità TEST)	43
14	Segnalazione allarmi e anomalie	44
15	Modalità INFO	45
16	Sblocco meccanico	46
17	Modalità di recupero posizione	46
18	Collaudo	47
19	Manutenzione	47
20	Smaltimento	47
21	Informazioni aggiuntive e contatti	48

## DEUTSCH

1	Allgemeine Sicherheitshinweise	80
	Konformitätserklärung	83
2	Symbole	84
3	Produktbeschreibung	84
4	Technische Daten des Produkts	85
5	Beschreibung der Anschlüsse	86
5.1	Art der Installation	86
5.2	Elektrische Anschlüsse	87
6	Befehle und Zubehör	88
7	Funktionstasten und Display	90
8	Einschalten oder Inbetriebnahme	90
9	Funktion Display	90
9.1	Parameter-Anzeigemodus	90
9.2	Anzeige des Status von Befehlen und Sicherheitseinrichtungen	91
9.3	TEST-Modus	91
9.4	Standby-Modus	91
10	Lernlauf	92
10.1	Zunächst	92
10.2	Einlernverfahren	93
11	Index der Parameter	94
12	Menü Parameter	97
13	Meldung der Sicherheitseingänge und der Befehle (TEST-Modus)	106
14	Meldung von Alarmen und Störungen	107
15	Diagnostik - Betriebsart Info	108
16	Mechanische Entriegelung	109
17	Modus zur Korrektur der Position	109
18	Abnahmeprüfung	110
19	Wartungsarbeiten	110
20	Entsorgung	110
21	Zusätzliche Informationen und Kontakte	110

## ENGLISH

1	General safety precautions	49
	Declaration of Conformity	51
2	Symbols	52
3	Product description	52
4	Technical characteristics of product	53
5	Description of connections	54
5.1	Typical installation	54
5.2	Electrical connections	55
6	Commands and Accessories	56
7	Function buttons and display	58
8	Switching on or commissioning	58
9	Display function modes	58
9.1	Parameter display mode	58
9.2	Command and safety device status display mode	59
9.3	TEST mode	59
9.4	Standby mode	59
10	Travel acquisition	60
10.1	Before starting	60
10.2	Acquisition procedure	61
11	Index of parameters	62
12	Parameters menu	65
13	Safety input and command status (TEST mode)	74
14	Alarms and faults	75
15	Procedural verifications - INFO Mode	76
16	Mechanical release	77
17	Position recovery mode	77
18	Initial testing	78
19	Maintenance	78
20	Disposal	78
21	Additional information and contact details	79

## FRANÇAIS

1	Consignes générales de sécurité	111
	Déclaration de conformité	113
2	Symboles	114
3	Description produit	114
4	Caractéristiques techniques produit	115
5	Description des raccordements	116
5.1	Installation type	116
5.2	Branchements électriques	117
6	Commandes et accessoires	118
7	Touches fonction et écran	120
8	Allumage ou mise en service	120
9	Modalités fonctionnement écran	120
9.1	Modalités affichage des paramètres	120
9.2	Modalité d'affichage d'état commandes et sécurités	121
9.3	Modalité TEST	121
9.4	Modalité Stand By	121
10	Apprentissage de la course	122
10.1	Avant de procéder	122
10.2	Procédure d'apprentissage	123
11	Indice des paramètres	124
12	Menu paramètres	127
13	Signalisation des entrées de sécurité et des commandes (modalités TEST)	136
14	Signalisations alarmes et anomalies	137
15	Diagnostic - Modalité info	138
16	Déblocage mécanique	139
17	Mode de récupération de position	139
18	Test	140
19	Entretien	140
20	Élimination	140
21	Informations complémentaires et contacts	141

**ESPAÑOL**

1	Advertencias generales	142
	Declaración de Conformidad	144
2	Símbolos	145
3	Descripción del producto	145
4	Características técnicas del producto	146
5	Descripción de las conexiones	147
5.1	Instalación básica	147
5.2	Conexiones eléctricas	148
6	Comandos y accesorios	149
7	Teclas de función y pantalla	151
8	Encendido o puesta en servicio	151
9	Modo de funcionamiento de la pantalla	151
9.1	Modos de visualización de los parámetros	151
9.2	Modos de visualización de indicaciones de seguridad y comandos	152
9.3	Modo de TEST	152
9.4	Modo Stand By	152
10	Aprendizaje del recorrido	153
10.1	Antes de actuar	153
10.2	Procedimiento de aprendizaje	154
11	Índice de los parámetros	155
12	Menú de parámetros	158
13	Señalización de las entradas de seguridad y de los comandos (Modo TEST)	167
14	Señalización de alarmas y anomalías	168
15	Diagnostica - Modo Info	170
16	Desbloqueo mecánico	170
17	Modo de recuperación de la posición	170
18	Ensayo	171
19	Mantenimiento	171
20	Eliminación	171
21	Información adicional y contactos	172

**PORTUGUÊS**

1	Advertências gerais	173
	Declaração de conformidade	175
2	Simbologia	176
3	Descrição do produto	176
4	Características técnicas do produto	177
5	Descrição das ligações	178
5.1	Instalação tipo	178
5.2	Ligações elétricas	179
6	Comandos e acessórios	180
7	Teclas de função e display	182
8	Ignição ou comissionamento	182
9	Modalidade de funcionamento do display	182
9.1	Modalidade de visualização dos parâmetros	182
9.2	Modalidade de visualização de estado dos comandos e dispositivos de segurança	183
9.3	Modalidade TESTE	183
9.4	Modalidade Stand By	183
10	Aprendizagem do curso	184
10.1	Antes de proceder	184
10.2	Procedimento de aprendizagem	185
11	Índice dos parâmetros	186
12	Menu dos parâmetros	189
13	Sinalização das entradas de segurança e dos comandos (modalidade TEST)	198
14	Sinalização de alarmes e anomalias	199
15	Diagnosticar - Modo INFO	200
16	Desbloqueio mecânico	201
17	Modo de recuperação de posição	201
18	Teste	202
19	Manutenção	202
20	Descarte	202
21	Informações adicionais e contatos	203


**DUTCH**

1	Algemene waarschuwingen	204
	Verklaring van Overeenstemming	206
2	Symbolen	207
3	Beschrijving product	207
4	Technische kenmerken product	208
5	Beschrijving aansluitingen	209
5.1	Type installatie	209
5.2	Elektrische aansluitingen	210
6	Bedieningen en accessoires	211
7	Functietoetsen en display	213
8	Inschakeling en inbedrijfsstelling	213
9	Bedrijfsmodus display	213
9.1	Modus van weergave parameters	213
9.2	Modus van weergave van de status bedieningen en veiligheden	214
9.3	TEST modus	214
9.4	Stand By modus	214
10	Lering van de slag	215
10.1	Voordat de handelingen worden uitgevoerd	215
10.2	Procedure van lering	216
11	Inhoudsopgave van de parameters	217
12	Menu parameters	220
13	Signalering van de veiligheidsingangen en van de bedieningen (modus TEST)	229
14	Signalering alarmen en storingen	230
15	Modus INFO	231
16	Mechanische deblokkering	232
17	Modus terugwinning positie	232
18	Test	233
19	Onderhoud	233
20	Inzameling	234
21	Bijkomende informatie en contact	234



**POLSKI**

1	Ostrzeżenia ogólne	235
	Deklaracja zgodności	237
2	Symbole	238
3	Opis urządzenia	238
4	Charakterystyka techniczna urządzenia	239
5	Opis połączeń	240
5.1	Rodzaj instalacji	240
5.2	Połączenia elektryczne	241
6	Elementy sterownicze i akcesoria	242
7	Przyciski funkcyjne i wyświetlacz	244
8	Włączanie lub uruchamianie	244
9	Tryby działania wyświetlacza	244
9.1	Wyświetlanie parametrów	244
9.2	Wyświetlanie statusu sygnałów sterowniczych i zabezpieczeń	245
9.3	Tryb TEST	245
9.4	Tryb Stand By	245
10	Programowanie ruchu	246
10.1	Wcześniej	246
10.2	Procedura programowania ruchu	247
11	Spis parametrów	248
12	Menu parametrów	251
13	Sygnalizacja wejść bezpieczeństwa i sygnałów sterowniczych (tryb TEST)	260
14	Sygnalizacja alarmowe i błędy	261
15	Tryb INFO	262
16	Odblokowanie mechaniczne	263
17	Tryb szukania pozycji	263
18	Testy odbiorcze	264
19	Konserwacja	264
20	Utylizacja	264
21	Informacje dodatkowe i dane kontaktowe	265



**FW**  
**P1.00**









Utilizzo alternativo dell'uscita COR (par. iB diverso da 00).  
 Alternative use of COR output (par. iB different from 00).




## COLLEGAMENTO CON 1 COPPIA FOTOCELLELE SINCRONIZZATE (MODALITÀ NORMALE, SOLO COPPIA MASTER) CONNECTION WITH 1 SYNCHRONISED PHOTOCELL PAIR (NORMAL MODE, MASTER PAIR ONLY)

ROSSO = libero da jumper  
RED = jumper free

4





JUMPER DI SINCRONIZZAZIONE (PER MASTER)  
SYNCHRONISATION JUMPER (FOR MASTER)



JUMPER DI ALLINEAMENTO (PER MASTER) OFF\*  
ALIGNMENT JUMPER (FOR MASTER) OFF\*

\* Per eseguire la modalità in di allineamento ottico (NOTA: consultare le istruzioni delle fotocellule):

\* To perform optical alignment mode (NOTE: refer to photocell instructions):



JUMPER DI ALLINEAMENTO ON\*  
ALIGNMENT JUMPER ON\*



**ATTENZIONE!** Modificare la posizione dei jumper di sincronizzazione o di allineamento solamente quando le fotocellule sono **NON ALIMENTATE!** La configurazione scelta con i jumper viene memorizzata dalle fotocellule solamente all'accensione delle fotocellule.

Scollegare la morsetteria della centrale che fornisce alimentazione alle fotocellule, oppure togliere completamente la tensione al controller digitale (scollegando, se presenti, anche le batterie di backup) e verificare nella fotocellula TX / RX che il LED rosso di alimentazione sia spento; procedere soltanto ora all'impostazione della configurazione dei jumper.


**ATTENTION!** Please ensure that the photocell jumpers are only changed with the power to the control panel switched off, including the disconnection of any battery backup. Remove the terminal of the photocell inputs or completely remove the voltage from the digital controller (check that the digital controller is not powered by backup batteries) and check that the TX / RX photocell red power LED is off.

SI RACCOMANDA L'USO DI fotocellule Serie F4ES - F4S / RECOMMENDED USE for Series F4ES - F4S photocells


**COLLEGAMENTO CON 2 COPPIE FOTOCELLE SINCROZZATE (MODALITÀ NORMALE, 1 MASTER E 1 SLAVE)**  
**CONNECTION WITH 2 SYNCHRONISED PHOTOCELL PAIRS (NORMAL MODE, 1 MASTER AND 1 SLAVE)**

ROSSO = libero da jumper  
 RED = jumper free

4



\* Per eseguire la modalità in di allineamento ottico (NOTA: consultare le istruzioni delle fotocelle):  
 \* To perform optical alignment mode (NOTE: refer to photocell instructions):



**ATTENZIONE!** Modificare la posizione dei jumper di sincronizzazione o di allineamento solamente quando le fotocelle sono **NON ALIMENTATE!** La configurazione scelta con i jumper viene memorizzata dalle fotocelle solamente all'accensione delle fotocelle.

Scollegare la morsetteria della centrale che fornisce alimentazione alle fotocelle, oppure togliere completamente la tensione al controller digitale (scollegando, se presenti, anche le batterie di backup) e verificare nella fotocella TX / RX che il LED rosso di alimentazione sia spento; procedere soltanto ora all'impostazione della configurazione dei jumper.

**ATTENTION!** Please ensure that the photocell jumpers are only changed with the power to the control panel switched off, including the disconnection of any battery backup. Remove the terminal of the photocell inputs or completely remove the voltage from the digital controller (check that the digital controller is not powered by backup batteries) and check that the TX / RX photocell red power LED is off.



**SI RACCOMANDA L'USO DI fotocelle Serie F4ES - F4S / RECOMMENDED USE for Series F4ES - F4S photocells**

# TEST FOTOCELLULE · PHOTOCELLS TEST (A8 02)


## COLLEGAMENTO CON 1 COPPIA FOTOCELLULE SINCRONIZZATE (MODALITÀ NORMALE, SOLO COPPIA MASTER) CONNECTION WITH 1 SYNCHRONISED PHOTOCCELL PAIR (NORMAL MODE, MASTER PAIR ONLY)

ROSSO = libero da jumper  
RED = jumper free

5





JUMPER DI SINCRONIZZAZIONE (PER MASTER)  
SYNCHRONISATION JUMPER (FOR MASTER)



JUMPER DI ALLINEAMENTO (PER MASTER) OFF\*  
ALIGNMENT JUMPER (FOR MASTER) OFF\*

\* Per eseguire la modalità in di allineamento ottico (NOTA: consultare le istruzioni delle fotocellule):  
\* To perform optical alignment mode (NOTE: refer to photocell instructions):



JUMPER DI ALLINEAMENTO ON\*  
ALIGNMENT JUMPER ON\*



**ATTENZIONE!** Modificare la posizione dei jumper di sincronizzazione o di allineamento solamente quando le fotocellule sono **NON ALIMENTATE!** La configurazione scelta con i jumper viene memorizzata dalle fotocellule solamente all'accensione delle fotocellule.

Scollegare la morsetteria della centrale che fornisce alimentazione alle fotocellule, oppure togliere completamente la tensione al controller digitale (scollegando, se presenti, anche le batterie di backup) e verificare nella fotocellula TX / RX che il LED rosso di alimentazione sia spento; procedere soltanto ora all'impostazione della configurazione dei jumper.


**ATTENTION!** Please ensure that the photocell jumpers are only changed with the power to the control panel switched off, including the disconnection of any battery backup. Remove the terminal of the photocell inputs or completely remove the voltage from the digital controller (check that the digital controller is not powered by backup batteries) and check that the TX / RX photocell red power LED is off.

SI RACCOMANDA L'USO DI fotocellule Serie F4ES - F4S / RECOMMENDED USE for Series F4ES - F4S photocells

# TEST FOTOCELLULE · PHOTOCELLS TEST (AB 02)

## COLLEGAMENTO CON 2 COPPIE FOTOCELLULE SINCRONIZZATE (MODALITÀ NORMALE, 1 MASTER E 1 SLAVE) CONNECTION WITH 2 SYNCHRONISED PHOTOCCELL PAIRS (NORMAL MODE, 1 MASTER AND 1 SLAVE)

ROSSO = libero da jumper  
RED = jumper free



\* Per eseguire la modalità in di allineamento ottico (NOTA: consultare le istruzioni delle fotocellule):  
\* To perform optical alignment mode (NOTE: refer to photocell instructions):



**ATTENZIONE!** Modificare la posizione dei jumper di sincronizzazione o di allineamento solamente quando le fotocellule sono **NON ALIMENTATE!** La configurazione scelta con i jumper viene memorizzata dalle fotocellule solamente all'accensione delle fotocellule.

Scollegare la morsetteria della centrale che fornisce alimentazione alle fotocellule, oppure togliere completamente la tensione al controller digitale (scollegando, se presenti, anche le batterie di backup) e verificare nella fotocellula TX / RX che il LED rosso di alimentazione sia spento; procedere soltanto ora all'impostazione della configurazione dei jumper.

**ATTENTION!** Please ensure that the photocell jumpers are only changed with the power to the control panel switched off, including the disconnection of any battery backup. Remove the terminal of the photocell inputs or completely remove the voltage from the digital controller (check that the digital controller is not powered by backup batteries) and check that the TX / RX photocell red power LED is off.

**SI RACCOMANDA L'USO DI** fotocellule Serie **F4ES - F4S** / **RECOMMENDED USE for** Series **F4ES - F4S** photocells



# BATTERY SAVING (AB 03)

# BATTERY SAVING + TEST FOTOCELLULE · PHOTOCELLS TEST (AB 04)


## COLLEGAMENTO CON 1 COPPIA FOTOCELLULE SINCRONIZZATE (MODALITÀ NORMALE, SOLO COPPIA MASTER) CONNECTION WITH 1 SYNCHRONISED PHOTOCCELL PAIR (NORMAL MODE, MASTER PAIR ONLY)

ROSSO = libero da jumper  
RED = jumper free

6



\* Per eseguire la modalità in di allineamento ottico (NOTA: consultare le istruzioni delle fotocellule):  
\* To perform optical alignment mode (NOTE: refer to photocell instructions):



**ATTENZIONE!** Modificare la posizione dei jumper di sincronizzazione o di allineamento solamente quando le fotocellule sono **NON ALIMENTATE!** La configurazione scelta con i jumper viene memorizzata dalle fotocellule solamente all'accensione delle fotocellule.

Scollegare la morsetteria della centrale che fornisce alimentazione alle fotocellule, oppure togliere completamente la tensione al controller digitale (scollegando, se presenti, anche le batterie di backup) e verificare nella fotocellula TX / RX che il LED rosso di alimentazione sia spento; procedere soltanto ora all'impostazione della configurazione dei jumper.

**ATTENTION!** Please ensure that the photocell jumpers are only changed with the power to the control panel switched off, including the disconnection of any battery backup. Remove the terminal of the photocell inputs or completely remove the voltage from the digital controller (check that the digital controller is not powered by backup batteries) and check that the TX / RX photocell red power LED is off.



**SI RACCOMANDA L'USO DI** fotocellule Serie **F4ES - F4S** / **RECOMMENDED USE for** Series **F4ES - F4S** photocells

# BATTERY SAVING (AB 03)

# BATTERY SAVING + TEST FOTOCELLULE · PHOTOCELLS TEST (AB 04)

## COLLEGAMENTO CON 2 COPPIE FOTOCELLULE SINCRONIZZATE (MODALITÀ NORMALE, 1 MASTER E 1 SLAVE) CONNECTION WITH 2 SYNCHRONISED PHOTOCCELL PAIRS (NORMAL MODE, 1 MASTER AND 1 SLAVE)

ROSSO = libero da jumper  
RED = jumper free



6

**A**  
JUMPER DI SINCRONIZZAZIONE (PER MASTER)  
SYNCHRONISATION JUMPER (FOR MASTER)


**B**  
JUMPER DI ALLINEAMENTO (PER MASTER) OFF\*  
ALIGNMENT JUMPER (FOR MASTER) OFF\*

**C**  
JUMPER DI SINCRONIZZAZIONE (PER SLAVE)  
SYNCHRONISATION JUMPER (FOR SLAVE)

**D**  
JUMPER DI ALLINEAMENTO (PER SLAVE) OFF\*  
ALIGNMENT JUMPER (FOR SLAVE) OFF\*

**E**  
JUMPER DI ALLINEAMENTO ON\*  
ALIGNMENT JUMPER ON\*

\* Per eseguire la modalità in di allineamento ottico (NOTA: consultare le istruzioni delle fotocellule):  
\* To perform optical alignment mode (NOTE: refer to photocell instructions):



**ATTENZIONE!** Modificare la posizione dei jumper di sincronizzazione o di allineamento solamente quando le fotocellule sono **NON ALIMENTATE!** La configurazione scelta con i jumper viene memorizzata dalle fotocellule solamente all'accensione delle fotocellule.


Scollegare la morsetteria della centrale che fornisce alimentazione alle fotocellule, oppure togliere completamente la tensione al controller digitale (scollegando, se presenti, anche le batterie di backup) e verificare nella fotocellula TX / RX che il LED rosso di alimentazione sia spento; procedere soltanto ora all'impostazione della configurazione dei jumper.

**ATTENTION!** Please ensure that the photocell jumpers are only changed with the power to the control panel switched off, including the disconnection of any battery backup. Remove the terminal of the photocell inputs or completely remove the voltage from the digital controller (check that the digital controller is not powered by backup batteries) and check that the TX / RX photocell red power LED is off.

SI RACCOMANDA L' USO DI fotocellule Serie F4ES - F4S / RECOMMENDED USE for Series F4ES - F4S photocells

7


**INSTALLAZIONE SU SERIE AY (AYRON) • MOTORE 1 (AY250M)**  
**AY SERIES (AYRON) INSTALLATION • MOTOR 1 (AY250M)**



**B71/BC**  
2 batteries  
12 Vdc 1,2 Ah  
type AGM

**COLLEGAMENTI CARICA BATTERIA SU SERIE AY (AYRON) • MOTORE 1 (AY250M)**  
**BATTERY CHARGER CONNECTION ON AY (AYRON) SERIES • MOTOR 1 (AY250M)**


8



2 batterie opzionali, installate su motore 2  
2 optional batteries, installed on motor 2  
12 Vdc 1,2 Ah type AGM

9



**INSTALLAZIONE BATTERIA SU SERIE AY (AYRON) • MOTORE 2 (AY250S)**  
**BATTERY INSTALLATION ON AY (AYRON) SERIES • MOTOR 2 (AY250S)**



**INSTALLAZIONE IN BOX (B70/2ML/BOX)**  
**BOX INSTALLATION (B70/2ML/BOX)**

10

**B71/BC/INT**  
 2 batteries  
 12 Vdc 1,2 Ah  
 type AGM



# 1 General safety precautions

---



## **WARNING: IMPORTANT SAFETY INSTRUCTIONS THESE INSTRUCTIONS MUST BE FOLLOWED TO GUARANTEE THE SAFETY OF THE PERSONS PRESERVE THESE INSTRUCTIONS**

This installation manual is intended for qualified personnel only.

 Failure to observe the information included in this manual may result in personal injury or damage to the equipment.

ROGER TECHNOLOGY cannot be held responsible for any damage or injury due to improper use or any use other than the intended usage indicated in this manual.

The installation, electrical connections and adjustments must be performed by qualified personnel, in accordance with best practices and in compliance with applicable regulations.

Read the instructions carefully before installing the product.

Incorrect installation may pose risks.

Before installing the product, make sure it is in perfect condition: In case of doubts, do not use the product and refer exclusively to professionally qualified personnel.

Do not install the product in explosive environment and atmosphere: inflammable gas or vapours constitute serious danger for safety.

Before installing the motor, make all structural modifications related to the safety precautions and to the protection or segregation of areas involving crushing, shearing, dragging risks or any other risks.

**WARNING:** check that the existing structure fulfils the required resistance and stability specifications.

ROGER TECHNOLOGY is not liable for failure to observe the good practices in the construction of fixtures to be motorised or for deformations that may occur during use.

The safety devices (photocells, sensing edges, emergency stops, etc.) must be installed taking into consideration the following: the regulations and directives in force, the good practices criteria, the installation environment, the operating logic of the system and the forces generated by the motorised door or gate.

The safety devices must protect any areas where there is crushing, shearing, dragging or any other danger in general generated by the motorised door or gate; the installer is advised to check that the moving wings do not have sharp edges or anything that may pose shearing and/or dragging risks.

If it is deemed necessary based on the risk analysis, install sensing edges on the mobile part.

It should be noted that, as provided by the UNI EN 12635 standard, all requirements of the EN 12604 and EN 12453 standards must be fulfilled and, if

necessary, also checked.

The European standards EN 12453 and EN 12445 define the minimum safety requirements for the operation of automatic doors and gates. In particular, these standards require the use of force limiting and safety devices (sensing ground plates, photocell barriers, hold-to-run operation, etc.) intended to detect persons or objects in the operating area and prevent collisions in all circumstances.

The installer is required to measure impact forces and select on the control unit the appropriate speed and torque values to ensure that the door or gate remains within the limits defined by the standards EN 12453 and EN 12445.

ROGER TECHNOLOGY cannot be held responsible for any damage or injury caused by the installation of incompatible components which compromise the safety and correct operation of the device.

If the hold-to-run function is active, the installer will have the obligation to check the maximum stop distance or the alternative use of the rubber deformable edge, the closing speed or the gate and in general all aspects indicated by the applicable regulations. Moreover, please note that if the command means is fixed, it must be located in a position guaranteeing the automation system control and operation and the command type and the use type must comply with the UNI EN 12453 standard, prospectus 1 (with the following restrictions: type A or B command or type 1 or 2 use).

In case of hold-to-run operation, remove any potential persons away from the range of action of the automation system's moving parts; the direct commands must be installed at a minimum height of 1.5 m and must not be accessible to the public; moreover, unless the device is key operated, they must be located with a direct view to the motorised part and far from the moving parts.

Apply the signs indicated by the regulations in force for the identification of the dangerous areas.

Each installed device must have a visible indication of the motorised door or gate identification data, in accordance with the EN 13241-1:2001 standard or subsequent revisions



A switch or an omnipolar cut-off switch with a contact opening of at least 3 mm must be installed on the mains power line; put the cut-off switch in OFF position and disconnect any buffer batteries before performing any cleaning or maintenance operations.

Ensure that an adequate residual current circuit breaker with a 0.03 A threshold and a suitable overcurrent cut-out are installed upstream the electrical installation in accordance with best practices and in compliance with applicable legislation.

When requested, connect the automation to an effective earthing system that complies with current safety standards.

The electronic parts must be handled using anti-static conductive wrist straps with grounding wire.

Only use original spare parts when repairing or replacing products.

The installer must provide the user with complete instruction for using the motorised door or gate in automatic, manual and emergency modes, and must

hand the operating instructions to the user of the installation upon completion. Keep away from hinges and moving parts.

Keep out of the area of action of the motorised door or gate while it is moving. Never try to stop the motorised door or gate while it is moving as this may be dangerous.

The motorised door or gate may be used by children aged 8 and above, by persons with diminished physical, sensory or mental capacity and by persons without the necessary experience and knowledge provided that they are supervised or have received adequate instruction on using the device safely and to ensure that they understand the dangers involved in its operation.

Children must be supervised at all times to ensure that they do not play with the device and that they keep out of the area of action of the motorised door or gate.

Keep remote controls and any other control devices out of the reach of children to prevent the risk of the motorised door or gate being operated unintentionally. Failure to observe these instructions may lead to danger.

Any repair or technical interventions must be performed by qualified personnel. The cleaning and maintenance operations must be performed exclusively by qualified personnel.

In the event of a fault or malfunction of the product, turn the main power switch off and have the installation serviced by qualified personnel and refrain from attempting to repair or perform any direct intervention yourself.

The packaging materials (plastic, polystyrene, etc.) should not be discarded in the environment or left within reach of children, as they are a potential source of danger.

Dispose of and recycle the packaging items according to the provisions of the laws in force.

These instructions must be kept and must be made available to any other persons authorised to use the installation.

## Declaration CE of Conformity

The undersigned Dino Florian, legal representative of Roger Technology - Via Botticelli 8, 31021 Mogliano V.to (TV) DECLARES that the **B70/2ML** digital control unit is compliant with the provisions established by Community directives:

- 2014/35/EU Direttiva LVD
- 2014/30/EU Direttiva EMC
- 2014/53/EU Direttiva RED
- 2011/65/CE Direttiva RoHS

Last two figures of year in which marking was applied **CE 20**.

Place: Mogliano V.to

Date: 07-05-2020

Signature



## 2 Symbols

The symbols and their meaning in the manual or on the product label are indicated below.

	<b>Generic danger.</b> Important safety information. Indicates operations and situations in which the personnel involved must pay close attention.
	<b>Dangerous voltage risk.</b> Indicates operations and situations in which the personnel involved must pay close attention to dangerous voltages.
	<b>Hot surfaces risk.</b> Indicates danger due to hot surfaces or which anyway have high temperatures (risk of burns).
	<b>Useful information.</b> Indicates useful information for the installation.
	<b>Refer to the Installation and use instructions.</b> Indicates the obligation to refer to the manual or original document, which must be available for future use and must not be damaged in any way.
	Protective earth connection point.
	Indicates the admissible temperature range.
	Alternating current (AC)
	Direct current (DC)
	Symbol for the product disposal according to the WEEE directive, see chapter 20.

## 3 Product description

The 24V **B70/2ML** control unit controls 1 or 2 ROGER brushless motors in sensorless mode for applications on medium sized gate leaves for residential use.

 **Ensure that the parameter  $R1$  is set correctly. If this parameter is not set correctly, the automation system may not function properly.**

Use the same type of motor for both gate leaves in automation installations for double leaf swing gates. Adjust the opening and closure speed, deceleration and delay settings appropriately for the specific installation, ensuring that the gate leaves overlap correctly.

ROGER TECHNOLOGY cannot be held responsible for any damage or injury due to improper use or any use other than the intended usage indicated in this manual.

We recommend using only ROGER TECHNOLOGY accessories and control and safety devices. Specifically, we recommend installing **F4ES** or **F4S** series photocells.

 **For further information, refer to the automation installation manual.**

## 4 Technical characteristics of product

	B70/2ML	B70/2ML/115
MAINS POWER VOLTAGE	230 Vac ± 10% 50 Hz	115 Vac ± 10% 50/60 Hz
MAXIMUM MAINS POWER ABSORPTION	150 W	
INRUSH POWER	350 W	
FUSES	<b>F1</b> = F3.15A (5x20 mm) accessories power supply protection <b>F2</b> = F15A (5x20 mm) engines power circuit protection <b>F3</b> = T1A (5x20 mm) Primary transformer protection	
CONNECTABLE MOTORS	2	
MOTOR POWER SUPPLY	24 Vac	
MOTOR TYPE	sinusoidal drive brushless (ROGER BRUSHLESS)	
MOTOR CONTROL TYPE	sensorless field oriented control (FOC)	
RATED MOTOR POWER	40 W	
MAXIMUM MOTOR POWER	110 W	
MAXIMUM POWER, FLASHING LIGHT	25 W (24 Vdc)	
FLASHING LIGHT DUTY CYCLE	50%	
MAXIMUM POWER	100 W 230 V~ - 40 W 24 V~ / --- (potential free contact)	
GATE OPEN LIGHT POWER	3 W 24 V---	
ELECTRIC LOCK POWER	15 W 12 V--- (medium voltage) (*)	
MAXIMUM ACCESSORY CURRENT ABSORPTION	10 W 24 V--- (400 mA)	
OPERATING TEMPERATURE	 -20°C  +55°C	
DEGREE OF PROTECTION	IP54	
PRODUCT DIMENSION	dimensions in mm 112x175 Weight: 0,23 kg	

(\*) The electric lock output provides a voltage of 24Vdc nominal (max 30Vdc) modulated to 50% (50% ON, 50% OFF). The device to be connected must therefore be able to withstand a maximum voltage of 30Vdc.




The total of the absorption values of all the accessories connected must not exceed the maximum power values shown in the table. The values are guaranteed with original ROGER TECHNOLOGY accessories ONLY. The use of non-original accessories may lead to malfunctioning. ROGER TECHNOLOGY declines all responsibility for incorrect or non-conforming installations.

All the connections are protected by fuses (refer to the table). The courtesy light requires an external fuse.

# 5 Description of connections

## 5.1 Typical installation



It is the installer's responsibility to verify the adequacy of the cables in relation to the devices used in the installation and their technical characteristics.

		Recommended cable
1	Power supply	H07RN-F 3x1,5 mm <sup>2</sup> double insulated cable
2	Motor 1	Cable 3x2,5 mm <sup>2</sup> (max 10 m) - 3x4 mm <sup>2</sup> (max 30 m) *
	Motor 2	Cable 3x2,5 mm <sup>2</sup> (max 10 m) - 3x4 mm <sup>2</sup> (max 30 m)
3	Photocells - Receiver <b>F4ES/F4S</b>	Cable 5x0,5 mm <sup>2</sup> (max 20 m)
4	Photocells - Transmitter <b>F4ES/F4S</b>	Cable 3x0,5 mm <sup>2</sup> (max 20 m)
5	LED Flashing light <b>FIFTHY/24</b> Power supply 24Vdc	Cable 2x1 mm <sup>2</sup> (max 10 m)
6	Antenna	Cable 50 Ohm RG58 (max 10 m)
7	Key selector <b>R85/60</b>	Cable 3x0,5 mm <sup>2</sup> (max 20 m)
	Key pad <b>H85/TTD - H85/TDS</b> (connecting to <b>H85/DEC - H85/DEC2</b> )	Cable 2x0,5 mm <sup>2</sup> (max 30 m)
	<b>H85/DEC - H85/DEC2</b> (connecting to control unit)	Cable 4x0,5 mm <sup>2</sup> (max 20 m) The number of conductors increases when using more than one output contact on <b>H85/DEC - H85/DEC2</b>
8	Gate open indicator Power supply 24V DC 3W max	Cable 2x0,5 mm <sup>2</sup> (max 10 m)
9	Courtesy light (Potential free contact) Power supply 230 Vac (100 W max)	Cable 2x1 mm <sup>2</sup> (max 20 m)

\* only for installations in BOX



**SUGGESTIONS:** with existing installations, we recommend checking the cross section of the cables and that the cables themselves are in good condition.

## 5.2 Electrical connections

A switch or an omnipolar cut-off switch with a contact opening of at least 3 mm must be installed on the mains power line; put the cut-off switch in OFF position and disconnect any buffer batteries before performing any cleaning or maintenance operations.

Ensure that an adequate residual current circuit breaker with a 0.03 A threshold and a suitable overcurrent cut-out are installed upstream the electrical installation in accordance with best practices and in compliance with applicable legislation.

For power supply, use a H07RN-F 3G1.5 type electric cable for AYRON installation or H07RN-F 2G1.5 for installation in box and connect it to the terminals L (brown), N (blue), (yellow/green), located inside the control panel box.


Strip the insulation from the ends of the power cable wires which will be connected to the terminal (fig. 1-2), and secure the cable with the cable retainer.

Measure the voltage on the primary mains power connection with a tester.

For the Brushless automation system to function correctly, the mains power voltage must be:






- 230Vac  $\pm 10\%$  for the B70/2ML control unit.
- 115Vac  $\pm 10\%$  for the B70/2ML/115 control unit.

If the detected value does not comply with the above specified values or is not stable, the automation system may NOT operate efficiently.



**i** Connections to the electrical distribution network and to any other low-voltage conductors in the external section to the electrical panel must be on an independent path and separate from the connections to the command and safety devices (SELV = Safety Extra Low Voltage).

Make sure that the mains power conductors and the accessory wires (24 V) are separated. The cables must be double insulated, strip them near the relevant connection terminals and lock them with clamps (not supplied).

	DESCRIPTION
	Installation on AYRON motor. Mains power supply 230 Vac $\pm 10\%$ 50 Hz connection. Fuse 5x20 T1A.
	Mains power supply 230 Vac $\pm 10\%$ 50 Hz connection. (115 Vac $\pm 10\%$ 60Hz). Installation on box. Fuse 5x20 T1A.
	Power supply input from transformer (or from B71/BC battery charger, if used). N.B.: Ready wired in factory by ROGER TECHNOLOGY.
<b>X-Y-Z</b> 	Connection to ROGER brushless MOTOR 1. <b>Warning!</b> If the motor rotates in the wrong direction, simply swap any two of the three motor connectors. Check the connections illustrated in fig. 1.
<b>Z-Y-X</b> 	Connection to ROGER brushless MOTOR 2. <b>Warning!</b> If the motor rotates in the wrong direction, simply swap any two of the three motor connectors. Check the connections illustrated in fig. 1.






## 6 Commands and Accessories


**!** If not installed, safety devices with NC contacts must be jumpered at the COM terminals, or disabled by modifying the parameters 50, 51, 53, 54, 73 and 74.

KEY:


N.A. (Normally Open) .

N.C. (Normally Closed).

CONTACT	DESCRIPTION
9 (COR)  10	Output (potential free contact) for connecting courtesy light. 230 Vac 100 W - 24 Vac/dc 40 W (fig. 3).
9 (COR) 10	Error alert contact only, for: <ul style="list-style-type: none"> <li>control unit in alarm / battery supply error (low battery);</li> <li>gate completely open / gate completely closed (fig. 3).</li> </ul> The COR output operating mode is managed by parameter 1B. The voltage level of the battery can be set via parameter B5.
20(+LAM)  19(COM)	Connection for flashing light (24 Vdc - duty cycle 50%) (fig. 2). The settings for the pre-manoeuve flashing warning signal may be selected with parameter A5, while the flashing mode is set with parameter 7B.
22(+ES)  21(COM)	Input for connecting electric lock, 12 Vdc max. 15 W (fig. 2). The function of the electric lock is determined by parameter 2B - 29.  Vmedia=12Vdc, Vmax=30Vdc; see table "PRODUCT TECHNICAL FEATURES" on page 51
18(+24V) 19(COM)	Power feed for external devices; see table "PRODUCT TECHNICAL FEATURES" on page 51
11(SC)  12(COM)	Connection for gate open indicator lamp. 24 Vdc 3 W (fig. 2). The function of the indicator lamp is determined by parameter AB.
11(SC)  12(COM)	Photocell test connection and/or battery saving (fig. 5 and 6). The power feed for the photocell transmitters (TX) may be connected to this. Set the parameter AB 02 to enable the test function. Each time a command is received, the control unit switches the photocells off and on to check that the contact changes state correctly. Power feeds for all external devices may be connected to reduce battery consumption (if batteries are used). Set AB 03 or AB 04. <b>WARNING!</b> If contact 20 (SC) is used for the photocell test function or battery saving function, a gate open indicator lamp cannot be connected.
24(FT2)  23(COM)	Input (N.C. or 8.2 kOhm) for connecting photocells FT2 (fig. 4-5-6). The photocells FT2 are configured by default with the following settings: <ul style="list-style-type: none"> <li>53 00 . Photocell FT2 disabled when gate is opening.</li> <li>54 00 . Photocell FT2 disabled when gate is closing.</li> <li>55 0 1 . The gate opens when an open command is received if photocell FT2 is obstructed.</li> <li>57 00 . NC (normally closed) incoming contact.</li> </ul> If the photocells are not installed, jumper the terminals 24(COM) - 23(FT2) or set the parameters 53 00 and 54 00. <b>WARNING!</b> Use R90/F4ES, G90/F4ES or T90/F4S series photocells.
25(FT1)  23(COM)	Input (N.C. or 8.2 kOhm) for connecting photocells FT1 (fig. 4-5-6). The photocells FT1 are configured by default with the following settings: <ul style="list-style-type: none"> <li>50 00 . Photocell triggers only during gate closure. Photocell is ignored during gate opening.</li> <li>51 02 . Movement is reversed if the photocell is triggered during gate closure.</li> <li>52 0 1 . The gate opens when an open command is received if photocell FT1 is obstructed.</li> <li>57 00 . NC (normally closed) incoming contact.</li> </ul> If the photocells are not installed, jumper the terminals 25(FT1) - 23(COM) or set the parameters 50 00 and 51 02. <b>WARNING!</b> Use R90/F4ES, G90/F4ES or T90/F4S series photocells.
28(ISEL)  26(COM)	Selectable input that can be configured as: <ul style="list-style-type: none"> <li>Clock input ORO (N.O. contact): by setting par. 60 to 00</li> <li>Sensing edge input COS (N.C. contact): by setting par. 60 to 0 1</li> </ul>
27(ST)  26(COM)	STOP command input (N.C. or 8.2 kOhm). The current manoeuvre is arrested if the safety contact opens. <b>N.B.:</b> the controller is supplied with this contact already jumpered by ROGER TECHNOLOGY. <ul style="list-style-type: none"> <li>57 00 . (normally closed) incoming contact.</li> </ul>
36 (ANT)  35	Antenna connector for slot-in radio receiver board. Use RG58 if an external antenna is used; maximum recommended length: 10 m. <b>N.B.:</b> do not make joints in cable.

CONTACT	DESCRIPTION
<b>16(AP)</b> <b>17(COM)</b> 	Open control signal input (N.O.). <b>IMPORTANT:</b> persistent activation of the opening command prevents automatic reclosure; the automatic reclosure time count is resumed when the opening command is released.
<b>15(CH)</b> <b>17(COM)</b> 	Close command input (N.O.).
<b>14(PP)</b> <b>17(COM)</b> 	Step by step mode command input (N.O.). The function of the control is determined by parameter <b>P4</b> .
<b>13(PED)</b> <b>17(COM)</b> 	Partial open control signal input (N.O.). On double leaf gate automation systems, by default, the partial opening command opens LEAF 1 completely. With single leaf swing gate installations, by default, partial opening is 50% of total opening.
<b>RECEIVER CARD</b>	Connector for plug-in radio receiver board. The control unit has two radio remote control functions by default: <ul style="list-style-type: none"> <li>- <b>PR1</b> - step mode command (modifiable with parameter <b>76</b>).</li> <li>- <b>PR2</b> - partial opening command (modifiable with parameter <b>77</b>).</li> </ul>
<b>BATTERY CHARGER B71/BC</b>	(Fig. 8-9) In the absence of mains voltage, the central network gets powered by the batteries, the display shows <b>BATL</b> and the flashing light gets activated with reduced frequency, until mains power is restored or until the battery voltage drops below the minimum permissible limit. In this case, <b>BATL</b> (Battery Low) is shown on the display and the control unit accepts no commands. If mains power is lost while the gate is moving (black out), the gate stops and then automatically resumes the interrupted manoeuvre after 2 seconds.
<b>BATTERY KIT</b> <b>2x12 Vdc 1,2 Ah</b> <b>(B71/BC/INT) *</b> <b>or</b> <b>2x12 Vdc 4,5 Ah</b> <b>(B71/BC/EXT)</b>  <b>Only AGM type.</b>  <b>* only for installations in BOX</b>	Two battery kits are available (fig.10): Two 12 V DC, 1.2 Ah batteries installed in the automation system itself. Two 12 V DC, 4.5 Ah batteries installed in an external case.  To reduce battery consumption, the positive power feed wire of the photocell transmitters and receiver may be connected to terminal <b>SC</b> (see fig. 5-6). Set <b>AB D3</b> or <b>AB D4</b> . In this configuration, the controller unit disconnects power from the accessory devices when the gate is completely open or completely closed.  <b>WARNING!</b> the batteries must always be connected to the electronic control unit in order to charge. Periodically (at least every 6 months), check that the batteries are in good working order.  For more information, refer to the installation manual for the <b>B71/BC</b> battery charger.

## 7 Function buttons and display



- Press the UP ▲ and/or DOWN ▼ buttons to view the parameter you intend to modify.
- Use the + and - buttons to modify the value of the parameter. The value starts to flash.
- Press and hold the + or - button to scroll quickly through values, to modify the parameter more quickly.
- To save the new value, wait a few seconds or move onto another parameter with the UP ▲ or DOWN ▼ button. The display flashes rapidly to indicate that the new value has been saved.
- Parameters can only be modified while the motor is not running. Parameters can be viewed at any time.

## 8 Switching on or commissioning


Power the control unit.  
The firmware version of the control unit is displayed briefly.  
Version installed: P1.00.



Immediately afterwards, the display enters the commands and safety device status mode. See chapter 7.


## 9 Display function modes

### 9.1 Parameter display mode



See chapter 11 for detailed descriptions of the parameters.

## 9.2 Command and safety device status display mode



**COMMAND STATUS:**  
The command status indicators on the display (segments AP = open, PP = step mode, CH = close, PED = partial opening, ORO= clock) are normally off. They illuminate when a command is received (e.g.: when a step mode command is received, the segment PP illuminates).


**SAFETY DEVICE STATUS:**  
The safety device status indicators on the display (segments FT1/FT2=photocells, COS= sensing edge, STOP) are normally on. If an indicator is off, the relative device is in alarm state or is not connected.

The an indicator is flashing, the relative device has been disabled with a specific parameter.  
\* NOTE: the segment ORO is only operated if par. 50 is 00; the segment COS only, if par. 50 is 0 1.


## 9.3 TEST mode

The TEST mode is used to test activation of the commands and safety devices with visual confirmation. To activate the mode, press the TEST button with the automatic gate system at rest. If the gate is moving, pressing TEST stops the gate. Pressing the button again enables TEST mode. If the flashing light and the gate open indicator lamp illuminate for one second each time a control is used or a safety device is activated.

The command signal status is shown on the left hand side of the display for 5 seconds, ONLY when the respective command signal is active (AP, CH, PP, PE, OR). For example, if the gate open command is activated, the letters AP appear on the display.




The status of the safety devices/inputs is shown on the right hand side of the display. The number of the terminal relative to the safety device in alarm state flashes. Example: STOP contact in alarm state.



**NOTA:** If one or more contacts are open, the gate will not open or close. If more than one safety device is in alarm state, once the problem relative to the first device is resolved, the alarm for the next device is displayed. Any further alarm states are also displayed with the same logic. Press the TEST button again to exit test mode. After 10 seconds with no user input, the display returns to command and safety device state display mode.

## 9.4 Standby mode

This mode is activated after 30 minutes with no user input. The POWER LED flashes slowly. Press UP ▲, DOWN ▼, +, - to reactivate the control unit.



# 10 Travel acquisition

**i** For the system to function correctly, the gate travel must be acquired by the control.


## 10.1 Before starting

1. Select the automation system model installed with the parameter *R 1*.


KEY:  **HIGH SPEED Motor**

SELECTION	MODEL		MOTOR TYPE	CONFIGURATIONS
<i>R 1 01</i>	<b>AYRON SERIES</b>			<b>NOTE: for gate leaves up to 2.5 m</b>
<i>R 1 02</i>	<b>BE20/200</b>		-	<b>NOTE: for gate leaves up to 3 m</b>
	<b>MONOS4</b>		-	<b>NOTE: for gate leaves up to 4 m</b>

2. Select the number of motors installed with the parameter *70*. This parameter is set for two motors by default.




3. Check that the operator present function is **NOT** enabled (*R7 00*).




4. Install mechanical stops in both the open and closed positions.

5. Move the gate into the closed position. The gate leaves must be against the mechanical stops.

6. Press TEST (see TEST mode in chapter 8) and check the command signal and safety device states. If any safety devices are not installed, jumper the relative contact or disable the device from the relative parameter (*50, 51, 53, 54, 73 and 74*).



## 10.2 Acquisition procedure:



- Press and hold PROG for 4 seconds. AP P- is shown on the display.
- Press **PROG** again. Auto is shown on the display.
- MOTOR 1 starts opening at low speed.
- After the delay time set with parameter 25 (with a default time setting of 3 s), MOTOR 2 starts an opening manoeuvre. Once the gate open mechanical stop is reached, the gate stops briefly. The message **AU tO** flashes on the display for 2 s.
- When the message **AU tO** stops flashing and is steadily lit on the display, MOTOR 2 closes first and then, after a delay set with parameter 25 (default setting 5 s), MOTOR 1 closes until the gate closed mechanical stop is reached.
- If the acquisition procedure is completed successfully, the display enters the command and safety device state display mode.

- If the following error messages are shown on the display, repeat the acquisition procedure:
- AP PE: acquisition error. Press the TEST button to clear the error, and check the safety device in alarm state.
  - AP PL: travel length error. Press TEST to clear the error, and check that both gate leaves are fully closed before launching a new acquisition procedure.

**i** For more information, see chapter 14 “Alarms and faults”.

# 11 Index of parameters


PARAM.	FACTORY DEFAULT	DESCRIPTION	PAGE
A1	SEE CHAP. 10	Selecting automation system model	65
A2	00	Automatic closure after pause time (from gate completely open)	65
A3	00	Automatic gate closing after mains power outage (black-out)	65
A4	00	Selecting step mode control function (PP)	65
A5	00	Pre-flashing	65
A6	00	Condominium function for partial open command (PED)	65
A7	00	Enabling operator present function	65
A8	00	Gate open indicator / photocell test function and "battery saving"	66
11	04	MOTOR 1 Setting deceleration during opening and closing	66
12	04	MOTOR 2 Setting deceleration during opening and closing	66
13	10	Adjusting LEAF 1 position control	66
14	10	Adjusting LEAF 2 position control	66
15	99	Partial opening adjustment (%)	66
18	00	Type of signaling provided by COR output	66
19	00	Adjusting MOTOR 1 stop advance on gate open stop	66
20	00	Adjusting MOTOR 2 stop advance on gate open stop	66
21	30	Setting automatic closing time	67
22	00	Enabling of management for opening with automatic reclosure exclusion	67
25	03	Adjusting opening delay of MOTOR 2	67
26	05	Adjusting closing delay of MOTOR 1	67
27	03	Setting reverse time after activation of sensing edge or obstacle detection (crush prevention)	67
28	00	Electric lock mode selection	67
29	00	Enable electric lock	67
30	07	Setting motor torque	67
31	15	Setting obstacle impact force sensitivity MOTOR 1	68
32	15	Setting obstacle impact force sensitivity MOTOR 2	68
33	10	Setting motor torque MOTOR 2	68
34	08	Setting start acceleration during opening and closing MOTOR 1	68
35	08	Setting start acceleration during opening and closing MOTOR 2	68
38	00	Enable lock release reverse impulse	68
40	04	Speed opening setting	68
41	04	Speed closing setting	68
43	00	Opening and closing approach distance setting MOTOR1	68
44	00	Opening and closing approach distance setting MOTOR2	68

PARAM.	FACTORY DEFAULT	DESCRIPTION	PAGE
49	01	Number of automatic closure attempts after activation of sensing edge or obstacle detection (crush protection)	68
50	00	Setting photocell mode during gate opening (FT1)	68
51	02	Setting photocell mode during gate closing (FT1)	69
52	01	Photocell (FT1) mode with gate closed	69
53	00	Setting photocell mode during gate opening (FT2)	69
54	00	Setting photocell mode during gate closing (FT2)	69
55	01	Photocell (FT2) mode with gate closed	69
56	00	Enable close command 6 s after activation of photocell (FT1-FT2)	69
57	00	Selecting contact type (NC or 8.2 kOhm) on inputs FT1/FT2/ST	69
58	00	Selecting the type of photocell test on input FT1	70
59	00	Selecting the type of photocell test on input FT2	70
60	01	ISEL selectable input configuration	70
65	05	Motor stop distance setting	70
70	02	Select number of motors installed	70
71	00	Enabling absolute encoder (SMARTY Series automation systems only)	70
73	03	Configuring sensing edge COS	70
76	00	Configuring radio channel 1 (PR1)	70
77	01	Configuring radio channel 2 (PR2)	70
78	00	Configuring flashing light frequency	71
79	60	Selecting courtesy light mode	71
80	00	Clock contact configuration ORO	71
81	00	Enable safeguarded gate closure/opening	71
82	03	Setting safeguarded closure/opening activation time	71
83	00	Selecting limitations in battery operation	71
84	00	Battery consumption selection	72
85	00	Selection of the battery operation management	72
90	00	Restoring factory default values	72
n0	01	HW version	72
n1	23	Year of manufacture	72
n2	45	Week of manufacture	72
n3	67	Serial number	72
n4	89		72
n5	01		72
n6	23	FW version	72
o0	01	View manoeuvre counter	72
o1	23		72

PARAM.	FACTORY DEFAULT	DESCRIPTION	PAGE
<i>h0</i>	<i>01</i>	View manoeuvre hour counter	72
<i>h1</i>	<i>23</i>		72
<i>d0</i>	<i>01</i>	View control unit days on counter	73
<i>d1</i>	<i>23</i>		73
<i>P1</i>	<i>00</i>	Password	73
<i>P2</i>	<i>00</i>		73
<i>P3</i>	<i>00</i>		73
<i>P4</i>	<i>00</i>		73
<i>CP</i>	<i>00</i>		Password change protection

# 12 Parameters menu

PARAMETER      PARAMETER  
VALUE



PARAMETER	PARAMETER VALUE
<b>A1 01</b>	<b>Selecting automation system model</b> <b>WARNING!</b> If this parameter is not set correctly, the automation system may not function properly. <b>N.B.:</b> in the event of a reset to restore the default parameters, this parameter must be set again manually.
01	<b>AYRON SERIES - IRREVERSIBLE</b> HIGH-SPEED gear motor with articulated arm
02	<b>BE20/200 - IRREVERSIBLE</b> arm piston with worm screw <b>MONOS4 - IRREVERSIBLE</b> telescopic arm piston
<b>A2 00</b>	<b>Automatic closure after pause time (from gate completely open)</b>
00	Disabled.
01-15	From 1 to 15 of gate closure attempts after photocell is triggered. Once the number of attempts set is reached, the gate remains open.
99	The gate tries to close indefinitely.
<b>A3 00</b>	<b>Automatic gate closing after mains power outage</b>
00	Disabled. The gate does not close automatically when mains power is restored.
01	Enabled. If the gate is NOT completely open, when mains power is restored, the gate closes after a 5 second warning signalled with the flashing light (independently of the value set with the parameter <b>A5</b> ). The gate closes in 'position recovery' mode (see chapter 17).
<b>A4 00</b>	<b>Selecting step mode control function (PP)</b>
00	Open-stop-close-stop-open-stop-close...
01	Condominium function: the gate opens and closes after the set automatic closing time. The automatic closing timer restarts if a new step mode command is received. Step mode commands are ignored while the gate is opening. This allows the gate to open completely and prevents the gate from closing when not required. If automatic closing is disabled ( <b>A200</b> ), the condominium function automatically attempts a closing manoeuvre <b>A201</b> .
02	Condominium function: the gate opens and closes after the set automatic closing time. The automatic closing timer does NOT restart if a new step mode command is received. Step mode commands are ignored while the gate is opening. This allows the gate to open completely and prevents the gate from closing when not required. If automatic closing is disabled ( <b>A200</b> ), the condominium function automatically attempts a closing manoeuvre <b>A201</b> .
03	Open-close-open-close.
04	Open-close-stop-open.
<b>A5 00</b>	<b>Pre-flashing</b>
00	Disabled. The flashing light is activated during opening and closing manoeuvres.
01-10	Flashing warning signal for 1 to 10 seconds prior to every manoeuvre.
99	5 second flashing warning signal prior to closing manoeuvre.
<b>A6 00</b>	<b>Condominium function for partial open command (PED)</b>
00	Disabled. The gate opens partially in step mode: open-stop-close-stop-open...
01	Enabled. Partial commands are ignored during gate opening.
<b>A7 00</b>	<b>Enabling operator present function</b>
00	Disabled.
01	Enabled. The open (AP) or close (CH) button must be pressed continuously to operate the gate. The gate stops when the button is released.

<b>88 00</b>	<b>Gate open indicator / photocell test function and "battery saving"</b>
00	The indicator is off when the gate is closed, and steadily lit during manoeuvres and when the gate is open.
01	The indicator flashes slowly during opening manoeuvres, and is lit steadily when the gate is completely open. It flashes quickly during closing manoeuvres. If the gate is stopped in an intermediate position, the lamp extinguishes twice every 15 seconds.
02	Set 02 if the output SC is used for the photocell test. See fig. 5. <b>NB:</b> the type of photocell test can be selected by means of parameters 58 and 59.
03	Set to 03 if the output SC is used for the "battery saving" function. See fig. 6. When the gate is completely open or closed, the control unit deactivates any accessories connected to terminal SC to reduce battery consumption.
04	Set to 04 if the output SC is used for the "battery saving" function and photocell test function. See fig. 6. <b>NB:</b> the type of photocell test can be selected by means of parameters 58 and 59.
<b>11 04</b>	<b>Setting deceleration MOTOR 1 during opening and closing</b>
<b>12 04</b>	<b>Setting deceleration MOTOR 2 during opening and closing</b>
01-05	01= the gate decelerates near stops and the limit switch (if installed). ... 05= the gate decelerates long before stops and the limit switch (if installed).
<b>13 10</b>	<b>Adjusting LEAF 1 position control when completely opens or closes</b> The value selected must ensure that LEAF 1 is opened/closed correctly when it reaches the respective (open or closed) mechanical stop. The position of LEAF 1 is calculated by the system from the number of motor revolutions and the motor reduction gear ratio. Warning! Excessively low values cause the gate to reverse when it reaches the gate open stop.
<b>14 10</b>	<b>Adjusting LEAF 2 position control when completely opens or closes</b> The value selected must ensure that LEAF 2 is opened/closed correctly when it reaches the respective (open or closed) mechanical stop. The position of LEAF 2 is calculated by the system from the number of motor revolutions and the motor reduction gear ratio. Warning! Excessively low values cause the gate to reverse when it reaches the gate closed stop.
01-20	motor revolutions (01 = minimum / 20 = maximum).
<b>15 99</b>	<b>Partial opening adjustment (%)</b> <b>N.B.:</b> with double leaf swing gate installations, this parameter is set by default as the completely open position of LEAF 1. With single leaf swing gate installations, this parameter is set to 50% of total opening.
15-99	From 15% to 99% of total gate travel.
<b>18 00</b>	<b>Type of signaling provided by COR output</b>
00	STANDARD operation managed by parameter 79
01	Contact closed if the control unit is working properly. Contact open if central locked in alarm.
02	Contact closed if the control unit is powered by the mains or charged battery. Open contact due to a fault: control unit powered by low battery (voltage level set by par. 85) or with error alert bE L0 (the control unit no longer accept commands).
03	Closed contact if none of the fault related situations 1 and 2 occurs. Open contact if at least one of the fault related situations 1 and 2 occurs
04	Closed contact if the gate is not completely open. Open contact if the gate is completely open.
05	Closed contact if the gate is not completely closed. Open contact if the gate is completely closed.
<b>19 00</b>	<b>Adjusting stop advance of LEAF 1 when opening</b>
<b>20 00</b>	<b>Adjusting stop advance of LEAF 2 when opening</b>
00	The leaf stops against the opening stop.
01-25	A leaf stop advance of 1 to 25 motor turns before the completely open position may be set.

<b>21 30</b>	<b>Setting automatic closing time</b> The timer starts from the gate open state and continues for the set time. Once the set time is reached, the gate closes automatically. The timer count restarts if a photocell is triggered. <b>IMPORTANT:</b> persistent activation of the opening command prevents automatic reclosure; the automatic reclosure time count is resumed when the opening command is released.
00-90	Pause time settable from 00 to 90 s.
92-99	Pause time settable from 2 to 9 min.

<b>22 00</b>	<b>Enabling of management for opening with automatic reclosure exclusion</b> If enabled, the exclusion of automatic reclosure only applies for the command selected via the parameter. For example: if you set <b>220 1</b> , automatic reclosure is excluded following an AP command, but it is activated following a PP or PED command. <b>NB:</b> a command activates a manoeuvre in the open-stop-close or close-stop-open sequence.
00	Disabled.
01	An AP (opening) command activates the opening manoeuvre. With the gate fully open, automatic reclosure is excluded. An AP (open) or CH (close) command activates the closure manoeuvre.
02	A PP (step mode) command activates the opening manoeuvre. With the gate fully open, automatic reclosure is excluded. Another PP (step mode) command activates the closure manoeuvre.
03	A PED (partial opening) command activates the partial opening manoeuvre. Automatic reclosure is excluded. Another PED (partial opening) command activates the closure manoeuvre.

<b>25 03</b>	<b>Adjusting opening delay (alignment) of MOTOR 2</b> During opening, MOTOR 2 starts with an adjustable delay after MOTOR 1.
00-10	From 0 to 10 s.

<b>26 05</b>	<b>Adjusting closing delay (alignment) of MOTOR 1</b> During closing, MOTOR 1 starts with an adjustable delay after MOTOR 2.
00-30	From 0 to 30 s.

<b>27 03</b>	<b>Setting reverse time after activation of sensing edge or obstacle detection (crush prevention)</b> This sets the reverse manoeuvre time after activation of the sensing edge or the obstacle detection system.
00-60	From 0 to 60 s.

<b>28 00</b>	<b>Electric lock mode selection</b>
00	Normally UNPOWERED electric lock (powered only for 3 s when opening starts). <b>N.B.:</b> The electric lock is enabled by parameter <b>29</b> .
01	"ventouse" type electric block (normally powered when the gate is completely closed). Not powered when gate is moving.
02	"ventouse" type electric block (normally powered when the gate is completely opened or completely closed). Not powered when gate is moving.
10-12	Electric lock of normally NOT powered type, with adjustable timing 10=0.5 seconds; 11=1 second; 12=1.5 seconds.

<b>29 00</b>	<b>Enable electric lock</b>
00	Disabled.
01	Enabled. When LEAF 1 approaches the gate closed stop, the controller delivers supplementary power to MOTOR 1 to latch the electric lock.
02	Enabled. When LEAF 1 approaches the gate closed stop, the controller delivers maximum power to MOTOR 1 to latch the electric lock. The obstacle detection system is disabled.

<b>30 07</b>	<b>Setting motor torque</b> Increasing or decreasing the value of the parameter increases or decreases motor torque and, as a result, adjusts obstacle detection sensitivity. Use values below <b>03</b> ONLY for particularly lightweight installations not exposed to severe weather conditions (strong winds or very cold temperatures). In installations with gate leaves of different lengths, they torque value may be set separately, setting a value for parameter <b>33</b> between <b>01</b> and <b>09</b> .
01-09	01=-35%; 02=-25%; 03=-16%; 04=-8% (reduced motor torque = increased sensitivity). 05=0%. 06=+8%; 07=+16%; 08=+25%; 09=+35% (increased motor torque = reduced sensitivity).

<b>3115</b>	<b>Setting obstacle impact force sensitivity MOTOR 1</b> If the reaction time to obstacle impact force is too long, reduce the value of the parameter. If the impact force exerted on obstacles is too high, reduce the value of parameter <b>30</b> . <b>N.B.:</b> repeat the acquisition procedure after any change made to this parameter.
<b>01-10</b>	Low motor torque: <b>01</b> = minimum obstacle impact force ... <b>10</b> = maximum obstacle impact force <b>N.B.:</b> only use these settings if the medium motor torque values are not suitable for the installation.
<b>11-19</b>	Medium motor torque. <b>Recommended setting for adjusting force settings correctly.</b> <b>11</b> = minimum obstacle impact force ... <b>19</b> = maximum obstacle impact force.
<b>20</b>	Maximum motor torque. <b>May only be used if the gate is equipped with a sensing edge.</b>
<b>3215</b>	<b>Setting obstacle impact force sensitivity MOTOR 2</b> If the reaction time to obstacle impact force is too long, reduce the value of the parameter. If the impact force exerted on obstacles is too high, reduce the value of parameter <b>30</b> (or <b>33</b> , if enabled; <b>33</b> different from <b>10</b> ). <b>N.B.:</b> repeat the acquisition procedure after any change made to this parameter.
<b>01-10</b>	Low motor torque: <b>01</b> = minimum obstacle impact force ... <b>10</b> = maximum obstacle impact force <b>N.B.:</b> only use these settings if the medium motor torque values are not suitable for the installation.
<b>11-19</b>	Medium motor torque. <b>Recommended setting for adjusting force settings correctly.</b> <b>11</b> = minimum obstacle impact force ... <b>19</b> = maximum obstacle impact force.
<b>20</b>	Maximum motor torque. <b>May only be used if the gate is equipped with a sensing edge.</b>
<b>3310</b>	<b>Setting motor torque MOTOR 2</b> Increasing or decreasing the value of the parameter increases or decreases motor torque and, as a result, adjusts obstacle detection sensitivity. Use values below <b>03</b> ONLY for particularly lightweight installations not exposed to severe weather conditions (strong winds or very cold temperatures).
<b>01-09</b>	<b>01</b> = -35%; <b>02</b> = -25%; <b>03</b> = -16%; <b>04</b> = -8% (reduced motor torque = increased sensitivity). <b>05</b> = 0%. <b>06</b> = +8%; <b>07</b> = +16%; <b>08</b> = +25%; <b>09</b> = +35% (increased motor torque = reduced sensitivity).
<b>10</b>	The torque is set with parameter <b>30</b> .
<b>3408</b>	<b>Setting start acceleration MOTOR 1 during opening and closing</b>
<b>3508</b>	<b>Setting start acceleration MOTOR 2 during opening and closing</b>
<b>01-10</b>	<b>01</b> = the gate accelerates rapidly at start of manoeuvre ... <b>10</b> = the gate accelerates slowly and progressively at start of manoeuvre.
<b>3800</b>	<b>Enable electric lock release reverse impulse</b>
<b>00</b>	Disabled.
<b>01</b>	Enabled. The controller applies a brief closing force (max. 4 s) to release the electric lock.
<b>4004</b>	<b>Setting opening speed (%)</b>
<b>4104</b>	<b>Setting closing speed (%)</b>
<b>01-05</b>	<b>01</b> = 60% minimum speed ... <b>05</b> = 100% maximum speed.
<b>4300</b>	<b>Opening and closing approach distance setting MOTOR1</b>
<b>4400</b>	<b>Opening and closing approach distance setting MOTOR2</b>
<b>00-80</b>	from min. <b>0</b> to max. <b>80</b> of turns performed by the motor at the minimum speed. <b>Speed is setted by the control unit automatically and it isn't adjustable.</b>
<b>4901</b>	<b>Setting number of automatic closure attempts after activation of sensing edge or obstacle detection (crush protection)</b>
<b>00</b>	No automatic closure attempts.
<b>01-03</b>	From 1 to 3 automatic closure attempts. We recommend setting a value equal to or lower than the value set for parameter <b>R2</b> . Automatic closure is only performed if the gate is completely open.
<b>5000</b>	<b>Setting photocell mode during gate opening (FT1)</b>
<b>00</b>	DISABLED. Photocell is not active or not installed.
<b>01</b>	STOP. The gate stops and remains stationary until the next command is received.
<b>02</b>	IMMEDIATE REVERSE. The gate reverses immediately if the photocell is activated during gate opening.

03	TEMPORARY STOP. The gate stops as long as the photocell is obstructed. The gate resumed opening when the photocell is cleared.
04	DELAYED REVERSE. The gate stops if the photocell is obstructed. The gate closes when the photocell is cleared.

### 5102 Setting photocell mode during gate closing (FT1)

00	DISABLED. Photocell is not active or not installed.
01	STOP. The gate stops and remains stationary until the next command is received.
02	IMMEDIATE REVERSE. The gate reverses immediately if the photocell is activated during gate closure.
03	TEMPORARY STOP. The gate stops as long as the photocell is obstructed. The gate resumed closing when the photocell is cleared.
04	DELAYED REVERSE. The gate stops if the photocell is obstructed. The gate opens when the photocell is cleared.

### 5201 Photocell (FT1) mode with gate closed N.B.: this parameter is not visible if ABO2 or ABO3 or ABO4 is set.

00	If the photocell is obstructed, the gate cannot open.
01	The gate opens when an open command is received, even if the photocell is obstructed.
02	The photocell sends the gate open command when obstructed.

### 5300 Setting photocell mode during gate opening (FT2)

00	DISABLED. Photocell is not active or not installed.
01	STOP. The gate stops and remains stationary until the next command is received.
02	IMMEDIATE REVERSE. The gate reverses immediately if the photocell is activated during gate opening.
03	TEMPORARY STOP. The gate stops as long as the photocell is obstructed. The gate resumed opening when the photocell is cleared.
04	DELAYED REVERSE. The gate stops if the photocell is obstructed. The gate closes when the photocell is cleared.

### 5400 Setting photocell mode during gate closing (FT2)

00	DISABLED. Photocell is not active or not installed.
01	STOP. The gate stops and remains stationary until the next command is received.
02	IMMEDIATE REVERSE. The gate reverses immediately if the photocell is activated during gate closure.
03	TEMPORARY STOP. The gate stops as long as the photocell is obstructed. The gate resumed closing when the photocell is cleared.
04	DELAYED REVERSE. The gate stops if the photocell is obstructed. The gate opens when the photocell is cleared.

### 5501 Photocell (FT2) mode with gate closed N.B.: this parameter is not visible if ABO2 or ABO3 or ABO4 is set.

00	If the photocell is obstructed, the gate cannot open.
01	The gate opens when an open command is received, even if the photocell is obstructed.
02	The photocell sends the gate open command when obstructed.

### 5600 Enable close command 6 s after activation of photocell (FT1-FT2) N.B.: This parameter is not visible if ABO3 or ABO4 is set. NOTE: in the case of photocells being blanked during opening, the 6 secs. count starts when the wings are completely open.

00	Disabled.
01	Enabled. When the photocell gate FT1 is crossed, a close command is sent 6 seconds later.
02	Enabled. When the photocell gate FT2 is crossed, a close command is sent 6 seconds later.

### 5700 Selecting contact type (NC or 8.2 kOhm) on inputs FT1/FT2/ST In conformity with the safety regulations EN12453-EN12445, devices using an 8.2 kOhm contact instead of an NC contact may be connected to inputs FT1/FT2/ST. The controller unit must therefore be configured accordingly.

	FT1	FT2	ST
00	The controller is configured for NC contacts by default.		
01	8k2	N.C.	N.C.
02	N.C.	8k2	N.C.
03	8k2	8k2	N.C.
10	N.C.	N.C.	8k2

11	8k2	N.C.	8k2
12	N.C.	8k2	8k2
13	8k2	8k2	8k2

**58 00 Selecting the type of photocell test on input FT1**  
 This parameter is visible if **AB02** or **AB04** is set.  
 If the photocell test is enabled, the control unit will check the photocells connected to input FT1 are working properly.  
 The test lasts max. 3 s OFF / 3 s ON.

**59 00 Selecting the type of photocell test on input FT2**  
 This parameter is visible if **AB02** or **AB04** is set.  
 If the photocell test is enabled, the control unit will check the photocells connected to input FT2 are working properly.  
 The test lasts max. 3 s OFF / 3 s ON.

- 00 Photocell test disabled.
- 01 Photocell test enabled on opening ONLY.
- 02 Photocell test enabled on closure ONLY.
- 03 Photocell test enabled on both opening and closure.

**60 01 ISEL selectable input configuration**  
 The parameter allows to configure the input and to make it available according to the type of the contact status for operating the clock or sensing edge.

- 00 ISEL is N.O. input and operates the clock function (configurable in par. 80)
- 01 ISEL is N.C. input and operates the COS function (configurable in par. 73)

**65 05 Setting motor stop distance**  
 01-05 01= faster deceleration/shorter stop distance ... 05= slower deceleration/longer stop distance.

**70 02 Select number of motors installed**

- 01 1 motor.
- 02 2 motors. IMPORTANT: Use the same type of motor for both gate leaves.

**73 03 Configuring sensing edge COS**  
**NOTE:** This parameter is visible only if par. 60 is 01

- 00 Sensing edge NOT INSTALLED.
- 01 NC contact (normally closed). The gate reverses only when opening.
- 02 Contact with 8k2 resistor. The gate reverses only when opening.
- 03 NC contact (normally closed). The gate always reverses.
- 04 Contact with 8k2 resistor. The gate always reverses.
- 12 Management of two 8k2 sensitive edges connected in parallel (total resistance 4k1). The gate reverses only when opening.
- 14 Management of two 8k2 sensitive edges connected in parallel (total resistance 4k1). The gate always reverses.

**76 00 Configuring radio channel 1 (PR1)**

**77 01 Configuring radio channel 2 (PR2)**

- 00 STEP MODE.
- 01 PARTIAL OPENING
- 02 OPENING
- 03 CLOSING.
- 04 STOP.
- 05 Courtesy light. The output COR is managed from the remote control. The light remains lit as long as the remote control is active. The parameter 79 is ignored.
- 06 Courtesy light ON-OFF (PP). The output COR is managed from the remote control. The remote control turns the courtesy light on and off. The parameter 79 is ignored.
- 07 STEP MODE with confirmation for safety. <sup>(1)</sup>
- 08 PARTIAL OPENING with confirmation for safety. <sup>(1)</sup>
- 09 OPENING with confirmation for safety. <sup>(1)</sup>
- 10 CLOSURE with confirmation for safety. <sup>(1)</sup>

<sup>(1)</sup> To prevent gate manoeuvres caused by accidentally pressing a remote control button, confirmation is required to enable the command. Example: parameters 76 07 and 77 07 set:

- Pressing the CHA button on the remote control selects the step mode function, which must be confirmed within 2 seconds by pressing CHB on the remote control. Press CHB to activate partial opening.

78 00 <b>Configuring flashing light frequency</b>	
00	The frequency is set electronically from the flashing light unit.
01	Slow flash.
02	Light flashes slowly when gate opens, rapidly when gate closes.

79 60 <b>Selecting courtesy light mode</b> <b>NOTE:</b> The parameter is not visible if par. 1B is other than 00	
00	Disabled.
01	PULSE. The courtesy light illuminates briefly at the start of each manoeuvre.
02	ACTIVE. The light remains lit for the entire duration of the manoeuvre.
03-90	From 3 to 90 s. The light remains lit for the time period set after the manoeuvre is completed.
92-99	From 2 to 9 minutes. The light remains lit for the time period set after the manoeuvre is completed.

80 00 <b>Clock contact configuration (ORO)</b> <b>NOTE:</b> This parameter is visible only if par. 60 is 00 When the clock function is active, the gate opens and remains open. At the end of the programmed time set with the external device (clock), the gate closes.	
00	When the clock function is active, the gate opens and remains open. Any command signal received is ignored.
01	When the clock function is active, the gate opens and remains open. Any command signal received is accepted. When the gate returns to the completely open position, the clock function is reactivated.


81 00 <b>Enable safeguarded gate closure/opening</b> Enabling this parameter ensures that the gate is not left open due to an incorrect and/or accidental command. This function is <b>NOT</b> enabled if: <ul style="list-style-type: none"> <li>• the gate receives a STOP command;</li> <li>• the sensitive edge intervenes, detecting an obstacle in the same direction in which the function is enabled. If instead the sensitive edge detects an obstacle during the movement opposite to the one guaranteed, the function remains active.</li> <li>• the number of closure attempts set by parameter B2 has been reached;</li> <li>• the acquired position is lost (perform position recovery, see chapter 17).</li> </ul>	
00	Disabled. The parameter B2 is not displayed.
01	Safeguarded closure enabled. After a period of time set with parameter B2, the control unit signals a 5 second warning with the flashing light, regardless of the parameter B5, and then closes the gate.
02	Safeguarded closure / opening enabled. If the gate is closed as a result of a step mode command, after a period of time set with parameter B2, the control unit signals a 5 second warning with the flashing light (regardless of the parameter B5), and then the gate closes. If the gate is stopped by the obstacle detection system during a closure manoeuvre, the gate closes after a period of time set with parameter B2. If the gate is stopped by the obstacle detection system during an opening manoeuvre, the gate closes after a period of time set with parameter B2.

82 03 <b>Setting safeguarded closure/opening activation time</b> <b>N.B.:</b> this parameter is not visible if the value of parameter B1 = 00.	
02-90	Wait time settable from 2 to 90 s.
92-99	Wait time settable from 2 to 9 min.

83 00 <b>Selecting limitations in battery operation</b> <b>N.B.:</b> the parameter is visible only if par. B5 is different than 00	
00	There is no limitation for the commands when the battery voltage drops under the selected threshold. An error alert may be activated via the COR output (if parameters B5 and 1B are adequately set).
01	When the battery voltage drops under the threshold selected with par. B5, the control unit accepts only opening commands and does not perform closing.
02	When the battery voltage drops under the threshold selected with par. B5, after a 5 s pre-flashing, the control unit automatically opens the barrier's boom and accepts only a closing command.
03	It accepts only closing commands even if the ORO input is active and if the parameter is 80 01.
04	When the battery voltage drops to the threshold selected with par. B5 the control unit, after a prelampping of 5s, automatically closes the gate and accepts only one opening command.

<b>84 00</b>	<b>Battery consumption selection</b>
00	Battery 24Vdc (2x12V). Acceleration/deceleration/speed reduction enabled, to increase the battery life. The activation of the flashing light is reduced (on 1 second, off 2 seconds).
01	Battery 24Vdc (2x12V). No performance reduction, maximum battery consumption. Activation of the flashing light is normal.

<b>85 00</b>	<b>Selection of the battery operation management</b>
	Setting a value different than 00 a battery voltage level check is activated. The desired operation type can be selected via parameter B3 and an error alert can be activated through the COR output via parameter IB.
00	The control unit always accepts commands until the battery is completely exhausted.
01	The command becomes active when the battery voltage drops to the minimum threshold (22Vdc for battery 2x12Vdc)
02	The command becomes active when the battery voltage drops to the medium threshold (23Vdc for battery 2x12Vdc)
03	The command becomes active when the battery voltage drops to the maximum threshold (24Vdc for battery 2x12Vdc)

<b>90 00</b>	<b>Restoring factory default values</b>
	<b>NOTE:</b> This procedure is only possible if NO data protection password is set.
	 <p>Warning! Restoring default settings cancels all settings made previously except for parameter A1: after restore, check that all parameters are suitable for the installation. The default factory settings may also be restored using the + (PLUS) and - (MINUS) buttons as follows:</p> <ul style="list-style-type: none"> <li>• Turn off the power.</li> <li>• Press and hold the + (PLUS) and - (MINUS) button until the unit switches on.</li> <li>• The display flashes after 4 s -E5-.</li> <li>• The default factory settings have now been restored.</li> </ul>

<b>Identification number</b>	
The identification number consists of the values of the parameters from n0 to n6.	
<b>N.B.:</b> The values shown in the table are indicative only.	
n0 01	<b>HW version</b>
n1 23	<b>Year of manufacture</b>
n2 45	<b>Week of manufacture</b>
n3 67	Example: 01 23 45 67 89 01 23
n4 89	
n5 01	
n6 23	
	<b>Serial number</b>
	<b>FW version</b>

<b>View manoeuvre counter</b>	
The number consists of the values of the parameters from o0 to o1 multiplied by 100.	
<b>N.B.:</b> The values shown in the table are indicative only.	
<b>IMPORTANT:</b> "manoeuvre" means every motor activation (total opening or closure / partial opening / step mode, etc.).	
o0 01	<b>Manoeuvres performed.</b>
o1 23	Example: 01 23 x100 = 12.300 manoeuvres.

<b>View manoeuvre hour counter</b>	
The number consists of the values of the parameters from h0 to h1.	
<b>N.B.:</b> The values shown in the table are indicative only.	
When the manoeuvre hour limit (set by B5 and B7) is exceeded, the visual maintenance signal is activated (e.g. every 1500 manoeuvre hours).	
<b>IMPORTANT:</b> "manoeuvre" means every motor opening activation.	
The message A55E is shown on the display and the flashing light, with motors stop, flashes with a regular duty cycle (1 s on / 4 s off) until system maintenance is performed and the alarm is reset.	
To reset the alarm, release the protection by inputting the password (EP 00) and press TEST for 5 s. The message A55E is displayed, followed by the messages UPdE flashing for 4 seconds: to reset the alarm, hold down the TEST key until d0E is displayed.	
If the TEST key is released, AbE appears on the display and the alarm is not reset.	
The number of hours H0-H1 is stored by the control unit, and the count is reset.	
If the value H0=99 H1=90 is exceeded (9990 hours of operation) the maintenance alarm is no longer managed.	
h0 01	<b>Manoeuvre hours.</b>
h1 23	Example: 01 23 = 123 hours.

<b>View control unit days on counter</b>	
The number consists of the values of the parameters from <i>d0</i> to <i>d1</i> . <b>N.B.:</b> The values shown in the table are indicative only.	
<i>d0 01</i>	<b>Days with unit switched on.</b> Example: <i>01 23</i> = 123 days.
<i>d1 23</i>	
<b>Password</b>	
Setting a password prevents unauthorised persons from accessing the settings. With password protection active ( <i>CP=01</i> ), parameters may be viewed, but the values CANNOT be modified. <u>Only a single password is used to control access to the gate automation system.</u> <b>WARNING:</b> Contact the Technical Support Service if you lose your password.	
<i>P1 00</i> <i>P2 00</i> <i>P3 00</i> <i>P4 00</i>	<p><b>Password activation procedure:</b></p> <ul style="list-style-type: none"> <li>• Enter the desired values for parameters <i>P1</i>, <i>P2</i>, <i>P3</i> and <i>P4</i>.</li> <li>• Use the UP ▲ and/or DOWN ▼ buttons to view the parameter <i>CP</i>.</li> <li>• Press and hold the + and - buttons for 4 seconds.</li> <li>• The display flashes to confirm that the password has been saved.</li> <li>• Switch the control unit off and on again. Check that password protection is activated (<i>CP=01</i>).</li> </ul> <p><b>Temporary unlock procedure:</b></p> <ul style="list-style-type: none"> <li>• Enter the password.</li> <li>• Check that <i>CP=00</i>.</li> </ul> <p><b>Password cancellation procedure:</b></p> <ul style="list-style-type: none"> <li>• Enter the password (<i>CP=00</i>).</li> <li>• Save the values <i>P1</i>, <i>P2</i>, <i>P3</i>, <i>P4</i> = <i>00</i></li> <li>• Use the UP ▲ and/or DOWN ▼ buttons to view the parameter <i>CP</i>.</li> <li>• Press and hold the + and - buttons for 4 seconds.</li> <li>• The display flashes to confirm that the password has been cancelled (the values <i>P1 00</i>, <i>P2 00</i>, <i>P3 00</i> and <i>P4 00</i> indicate that no password is set).</li> <li>• Switch the control unit off and on again (<i>CP=00</i>).</li> </ul>
<b><i>CP 00</i> Changing password</b>	
<i>00</i>	Protection deactivated.
<i>01</i>	Protection activated.

# 13 Safety input and command status (TEST mode)

With no currently active commands, press the TEST button and check the following:

DISPLAY	POSSIBLE CAUSE	ACTION BY SOFTWARE	PHYSICAL CORRECTIVE ACTION
88 27	The safety <b>STOP</b> contact is open. Incorrect setting of parameter 57.	Check that parameter 57 is set correctly	Install a <b>STOP</b> button (NC) or jumper the ST contact with the <b>COM</b> contact.
88 28	Sensing edge <b>COS</b> not connected or incorrectly connected. NOTE: visible only if par. 60 is 0 1	Set the parameter 73 00 if not used or to disable.	Jumper contact <b>ISEL</b> with contact <b>COM</b> , if not used or to disable
88 25	Photocell <b>FT1</b> not connected or incorrectly connected. Incorrect setting of parameter 57.	Set the parameter 50 00 and 51 00 if not used or to disable.	Jumper contact <b>FT1</b> with contact <b>COM</b> , if not used or to disable. Check connection referring to relative connection diagram (figure 4).
88 24	Photocell <b>FT2</b> not connected or incorrectly connected. Incorrect setting of parameter 57.	Set the parameter 50 00 and 51 00 if not used or to disable.	Jumper contact <b>FT2</b> with contact <b>COM</b> , if not used or to disable. Check connection referring to relative connection diagram (figure 4).
PP 00	If occurs with no voluntary command, the contact (N.O.) may be faulty or one of the buttons may be incorrectly connected.	-	Check <b>PP - COM</b> contacts and connections to buttons.
CH 00		-	Check <b>CH - COM</b> contacts and connections to buttons.
AP 00		-	Check <b>AP - COM</b> contacts and connections to buttons.
PE 00		-	Check <b>PED - COM</b> contacts and connections to buttons.
Qr 00	If occurs with no command, the contact (N.O.) may be faulty or the timer may be incorrectly connected. NOTE: visible only if par. 60 is 00	-	Check <b>ISEL - COM</b> contacts. Contact must not be jumpered if not used.

**N.B:** press TEST to exit TEST mode.

We recommend troubleshooting safety device and input status errors with "corrective action by software" only.


# 14 Alarms and faults

PROBLEM	ALARM	POSSIBLE CAUSE	ACTION
The gate does not open or close.	POWER LED off	No mains power.	Check the mains power cable.
	POWER LED off	Fuses blown. Check fuses F1, F2 and F3.	Replace fuse. Always disconnect from mains power before removing fuses.
	OF St	Input mains power voltage fault. Control initialisation failed.	Disconnect from mains power, wait 10 seconds then reconnect to the mains and switch on. If the problem persists, contact your local authorized dealer for verification and possible assistance. Pressing the TEST button it is possible to hide the alarm temporarily and consult the control unit's parameters.
	Pr Ot	Overcurrent detected in inverter.	Press the <b>TEST</b> button twice or perform 3 command requests in succession.
	dAtA	Incorrect travel length values.	Press the TEST button and check the safety device/s in alarm state and the connections of the safety devices. Check that the mechanical stops of MOTOR 1 and MOTOR 2 are positioned correctly. Repeat acquisition procedure.
	Not 1	Motor 1 not connected.	Check the motor cable.
	Not 2	Motor 2 not connected.	Check the motor cable.
	Example: 15 EE 21 EE	Configuration parameter error.	Set configuration value correctly and save.
	btLO (btLO)	Flat batteries.	Wait for mains power to be restored.
Acquisition procedure does not complete correctly.	AP P.E	TEST button pressed accidentally.	Repeat acquisition procedure.
		Safety devices in alarm state.	Press the TEST button and check the safety device/s in alarm state and the connections of the safety devices.
		Excessive voltage drop.	Repeat acquisition procedure. Check mains voltage.
	AP PL	Travel length error.	Move gate into completely closed position and repeat the procedure.
Remote control has limited range and does not work while automated gate is moving.	-	The radio transmission is impeded by metal structures and reinforced concrete walls.	Install the antenna.
	-	Flat batteries.	Replace the transmitter batteries.
The flashing light is not working.	-	Bulb / LED blown or flashing light wires disconnected.	Check LED circuit and/or connector wires.
Gate open indicator lamp does not work.	-	Bulb blown or wires disconnected.	Check the bulb and/or wires.
Gate does not perform desired manoeuvre.	-	Motor leads crossed.	Swap two wires on terminal X-Y-Z or Z-Y-X.

**N.B.:** Press the TEST button to temporarily cancel the alarm.

The next time a command is received, the alarm reappears on the display if the problem has not been resolved.

# 15 Procedural verifications - INFO Mode



INFO mode may be used to view certain parameters measured by the **B70/2ML** controller.

Press and hold the **TEST** button for 5 seconds from the "View command signals and safety devices" mode with the motor stationary. The control unit displays the following parameters and the corresponding measured values in sequence:


Parameter	Function
<i>P 1.00</i>	View for 3 s the firmware version of the control unit.
<i>Cnt 1</i> <i>Cnt 2</i>	Displays the position of MOTOR 1 / MOTOR 2, expressed in revolutions and relative to total length, at the time of the test.
<i>Lun 1</i> <i>Lun 2</i>	View total length of MOTOR 1/ MOTOR 2 programmed travel , in motor revolutions.
<i>rPn 1</i> <i>rPn 2</i>	View MOTOR 1 /MOTOR 2 speed, in revolutions per minute (rpm).
<i>ANP 1</i> <i>ANP 2</i>	View current absorption of MOTOR 1/MOTOR 2, in Amperes (e.g.: 001.1 = 1,1 A ... 016.5 = 16,5 A). If the MOTOR 1 / MOTOR 2 is stationary, the current absorption value is 0. Activate a command function to test current absorption.
<i>bUS</i>	System OK indicator. To check for overloading (e.g.: too many utilities connected to 24 V output) or if the mains voltage is too low, compare the parameters read with values indicated as follows with the motor stationary: mains voltage= 230 Vac (nominal), bUS= 28.5 mains voltage= 207 Vac (-10%), bUS= 25.5 mains voltage= 253 Vac (+10%), bUS= 31.6
<i>CNP 1</i> <i>CNP 2</i>	Display current, expressed in Amperes, used to compensate for strain detected by MOTOR 1 / MOTOR 2 due, for example, to low external temperatures (e.g.: 0 = 0 A ... 4 = +3 A). At the beginning of a manoeuvre from the completely open or completely closed position, if the control unit detects a strain higher than the value stored in its memory during the travel acquisition cycle, the controller automatically increases the current delivered to MOTOR 1 / MOTOR 2.
<i>ASC 1</i> <i>ASC 2</i>	Display current threshold, expressed in Amperes, at which the obstacle detection function (crush prevention) of MOTOR 1 / MOTOR 2 is triggered. This value is calculated automatically by the controller in relation to the settings of parameters 30, 31 and 32. For the motor to function correctly, <i>ANP</i> must always be lower than the value <i>ASC</i> .
<i>tIn 1</i> <i>tIn 2</i>	Indicates time taken by motor to detect an obstacle, as set with parameter 31/32, in seconds. E.g. 1.000 = 1 s / 0.120 = 0.12 s (120 ms). Ensure that the manoeuvre time is more than 0.3 s.
<i>AbS 1</i> <i>AbS 2</i>	MOTOR 1 / MOTOR 2 status OK indicator. In normal conditions, this value is less than 500. If the value exceeds 2000, the controller disables the motor. A value exceeding 500 indicates that the characteristics of the connection cable are inadequate for the installation or that the connection cable is too long or of inadequate cross section, or may indicate an electrical fault of the brushless motor.
<i>UP</i>	If the control unit is capable of identifying the position of the gate leaf when the test is conducted, the following is shown on the display: <i>UP</i> - - position known, normal operation. <i>UP</i> L - LEAF 1 position unknown, position recovery in progress. <i>UP</i> L - LEAF 2 position unknown, position recovery in progress. <i>UP</i> I2 positions of both leaves unknown, position recovery in progress.
<i>OC</i>	Indicates the state of the automation system (open/closed). <i>OC</i> OP automation system opening (motor active). <i>OC</i> CL automation system closing (motor active). <i>OC</i> -D automation system completely open (motor not actives). <i>OC</i> -C automation system completely closed (motor not actives).
<i>UF</i>	<i>UF</i> U - mains voltage too low or overload. <i>UF</i> -H motors overcurrent.

- If only one motor is connected to the control unit, the parameters relative to "MOTOR 1" only are displayed.
- Use the + / - buttons to scroll through the parameters. When the last parameter in the sequence is reached, press the - button to return through the previous parameters.
- In INFO mode, the automation system may be activated to test operation in real time.
- The two motors may be controlled independently in OPERATOR PRESENT mode, ignoring the position data request message "dRAA" and bypassing the safety devices installed (photocells, sensing edges and STOP button) with the exception of the obstacle detection system. MOTOR 1 is controllable when the messages: *Cnt 1*, *rPn 1*, *ANP 1* and *AbS 1* appear on the display. MOTOR 2 is controllable when the messages: *Cnt 2*, *rPn 2*, *ANP 2* and *AbS 2* appear on the display.

Example:




### 1-PRESS



### 2-RELEASE



### 3-RE-PRESS



- THE MOTOR in question is activated on opening by pressing the ▲ "UP ARROW" key, or on closure by pressing the ▼ "DOWN ARROW" key.
- For safety, the open and close functions are only available in continuous control (operator present) mode: press the button, release within 1 second and then press and hold. The motor stops as soon as the button is released. **WARNING: during the check, the motor revolution count (position) is updated but the gate leaf alignment control function may cause problems. Before exiting INFO, make sure that the gate leaves are correctly aligned.**
- Press and hold the **TEST** button for a few seconds to exit INFO mode.

## 16 Mechanical release

In the event of power failure, the gate may be unlocked by following the instructions given in the use and maintenance manual of the automation system. On receiving the first command signal after mains power is restored, the control unit starts an opening manoeuvre in position recovery mode (see chapter 17).

## 17 Position recovery mode

On receiving the first command signal after a power failure or after detecting an obstacle in the same position three consecutive times, the control unit starts a manoeuvre in position recovery mode.


When the controller received a command signal, the gate starts a manoeuvre at low speed. The flashing light flashes with a different duty cycle than normal (3 s on, 1.5 s off).

In this phase the control unit performs a series of operations to recover the correct position in the opening and closing directions. **Warning!** During the position recovery phase, do not activate any command and do not obscure the photocells until the gate has performed a complete opening and closing manoeuvre for both leaves.

### RELEASE OF THE GATE LEAVES WITH POWERED CONTROL UNIT

If both gate leaves are released from a completely open or completely closed position, to obtain the regular functioning of the gate, simply reposition the leaves in the position they had when they were released. The gate will resume normal operation on receipt of the first control command.

**WARNING:** If one or both leaves are released when they are completely closed, to manually open the gateway, the loss of position data of the leaves occurs. In this case, the position recovery must be performed as shown in the following illustration.



## POSITION RECOVERY WITH CONTROL UNIT NOT POWERED (BLACK OUT) AND INTERMEDIATE POSITION OF LEAVES (NOT COMPLETELY CLOSED OR NOT COMPLETELY OPEN)

NOTE: if set to par.  $\text{P3 0 1}$  and a blackout occurs, when the mains voltage returns, in whatever position the leaves are, after a pre-flashing of 5 seconds the closing manoeuvre is activated at low speed.

At the next command, the gate leaves perform the opening manoeuvre at low speed to restore normal operating mode.

NOTE: If the control unit is not powered (blackout) and parameter  $\text{P3}$  is at  $\text{00}$ , upon receipt of a command, the repositioning procedure begins, which will be completed when the leaves have performed a complete run without interruption.

## 18 Initial testing

---

The testing must be performed by qualified technical personnel.

The installer is required to measure impact forces and select on the control unit the appropriate speed and torque values to ensure that the motorised door or gate remains within the limits defined by the standards EN 12453 and EN 12445.

Make sure that the provisions in Chapter 1 "GENERIC WARNINGS are observed.

- Turn on the power supply.
- Check that the automation system motors rotate in the correct direction. If the leaves do not move correctly, swap any two of the wires on the X-Y-Z motor terminal.
- Check that all connected controls are working correctly.
- Check travel and deceleration.
- Check that the impact force is correct, in compliance with EN 12453 and EN12445.
- Check that the safety devices are activated correctly.
- If the photocell test is enabled, check it is working properly by obscuring the photocells and giving a command: the gate leaves must not move.
- If the battery kit is installed, disconnect from mains and check that the batteries are working.
- Disconnect from mains power and disconnect the batteries (if used), then reconnect. Check the correct completion of the position recovery phase when opening and when closing.

## 19 Maintenance

---

Perform scheduled maintenance every 6 months.

Check cleanliness and function.

If the unit contains dirt, moisture, insects or other foreign matter, disconnect from mains power and clean the board and the housing.

Repeat the initial installation test procedure after cleaning.

If any corrosion is found on the printed circuit board, evaluate if it is necessary to replace the board itself.

Check that the battery is in good working order.

## 20 Disposal

---



The product may only be uninstalled by qualified technical personnel, following suitable procedures for removing the product correctly and safely. This product consists of numerous different materials. Some of these materials may be recycled, while others must be disposed of correctly at the specific recycling or waste management facilities indicated by local legislation applicable for this category of product.

Do not dispose of this product as domestic refuse. Observe local legislation for differentiated refuse collection, or hand the product over to the vendor when purchasing an equivalent new product.

Local legislation may envisage severe fines for the incorrect disposal of this product. **Warning!** Some parts of this product may contain substances that are harmful to the environment or dangerous and which may cause damage to the environment or health risks if disposed of incorrectly.

## 21 Additional information and contact details

---

ROGER TECHNOLOGY is the exclusive proprietor holder of all rights regarding this publication. ROGER TECHNOLOGY reserves the right to implement any modifications without prior notification. Copying, scanning or any alterations to this document are prohibited without express prior authorised from by ROGER TECHNOLOGY.

ROGER TECHNOLOGY reserves the right to modifying or perfecting the product, which will not imply a FW version change.

In the absence of an instruction manual revision, it is understood that these instructions hold good for this and for subsequent FW versions of the control unit.

This instruction manual and the warnings for the installer are given in printed form and are included in the box containing the product.

The digital version of this documentation (PDF) and any future updates are available from the reserved area of our website **[www.rogertechnology.com/B2B](http://www.rogertechnology.com/B2B)**, in the Self Service section.

### **ROGER TECHNOLOGY CUSTOMER SERVICE:**

business hours: Monday to Friday  
08:00 to 12:00 - 13:30 to 17:30

Telephone no: +39 041 5937023

E-mail: [service@rogertechnology.it](mailto:service@rogertechnology.it)

Skype: service\_rogertechnology

To request support for any problems or for any other queries regarding the automation system, please compile the online form "REPAIRS" in the 'Self Service' area of our website [www.rogertechnology.com/B2B](http://www.rogertechnology.com/B2B).







**ROGER TECHNOLOGY**  
Via S. Botticelli 8 • 31021 Bonisiolo di Mogliano Veneto (TV) • ITALIA  
P.IVA 01612340263 • Tel. +39 041.5937023 • Fax. +39 041.5937024  
info@rogertechnology.com • [www.rogertechnology.com](http://www.rogertechnology.com)